



Poppit Pads Usage Guide

Fix your panels in 4 easy steps using BigBond self-adhesive pads:

Preparation: Remove dust, dirt, oil or grease from both surfaces, ensuring they are clean and dry.

Step 1



Stick the pad onto the Poppit.

Step 2



Stick the Poppits to the panel. You can stick either the male (steel) or female (plastic) side to your panel. The pads should bond the Poppits instantly.

Step 3



Stick the pad onto the Poppit.

Step 4



Press the panel to the wall with even pressure. 70% of the full sticking power is reached after 1 hour and full strength after 24 hrs.

Important Notice: All technical information contained within this document is based on actual results achieved by Bighead Bonding Fasteners Ltd (BBFL) within a controlled test environment and relate solely to the test criteria applicable. BBFL can accept no responsibility whatsoever for adhesive bonding performance obtained by others over whose installation methods BBFL has no control. It is the user's responsibility to determine product suitability for any specific purpose/application. BBFL may provide a sample for this purpose upon request.